



Z3X2 INSTALLATION INSTRUCTIONS



Step 1 Install carb mounting studs.



Step 2 Install carb base gaskets.




Step 3 Install center carb (one with choke).



Step 4 Install outboard carbs. You may have to tip carbs to place them on intake.




Step 5 Make sure all carbs are sitting flat on intake.




Step 6 Install carb mounting nuts.

Z3X2 INSTALLATION INSTRUCTIONS




Step 7 Once you have all carb nuts installed, check throttle opening on each carb then tighten nuts (caution don't over tighten).




Step 8 Install fuel lines finger tight. Do not fully tighten until all lines are installed.




Step 9 Continue installing fuel lines



Step 10 Continue installing fuel lines



Step 11 Once all fittings are installed finger tight, tighten with wrench.




Step 12 Check to see that all fittings are properly tightened.

Z3X2 INSTALLATION INSTRUCTIONS



Step 13 Plug hot wire onto choke cap.




Step 14 Thread throttle rods into truions on center carb do not tighten locking nut at this time.




Step 15 To adjust carb throttle, hold carbs full throttle and adjust rods so outboard carbs are fully open as shown in next two photos.



Outboard carb must be fully open.




Outboard carb must be fully open.



Step 16 Place washer and wire clip in end carb throttle pins


Z3X2 INSTALLATION INSTRUCTIONS




Step 17 Tighten lock nut at this time, caution do not over tighten.



Step 18 Place air cleaner studs in carbs and tighten. (Caution do not over tighten).




Step 19 Place air cleaner base gaskets on all carbs.



Step 20 Place air cleaner on carbs install washer and chrome nut.



Don't over tighten air cleaner nut.



Completed installation.